



Senha de 2º Nível


Guia de utilização para criar a senha de 2º nível

Senha de 2º Nível – Criando acesso

Introdução

Fazendo o registro no site “Registration” para fazer a senha de segundo nível e acessar o menu de serviço no inversor

Menu Settings



Registration

Para acessar o menu “Service” e alterar os parametros de **Localização e Rede (Grid)** é necessário entrar no site **Registration**. Conforme o endereço abaixo.

<https://registration.abbsolarinverters.com>

Senha de 2º Nível – Criando acesso

Introdução

Fazendo o registro no site “Registration” para fazer a senha de segundo nível e acessar o menu de serviço no inversor

Registration

Welcome to the registration page of Power-One services!

Language: English

Sign up for Power-One service to receive a password which will allow you to enter the reserved area where you can download the advanced configurations and inverter FW updating. This password will also allow you to enter the configuration SW of inverters as "installer".

From "installer" interface you can modify the internal parameters of inverters in accordance with the law in force. To log in as an installer you need an access password and the data used for the registration. You will have to reenter the password and your registration data.

Entering the reserved area also allows you to have a password to access the service menu of inverter display in order to change the protections, change the protections operation threshold).

To receive the password you need to enter the S/N (serial number), the WK (production week) and the Update version for the inverter. The information are available in the inverter menu → S/N and INFORMATION → Firmware) and, on the inverter display, in the menu → S/N and INFORMATION → Firmware). The entering process will last longer than 14 days from its calculation.

Not registered? Go to the registration page. You will receive an email with the password for all services.

Sign Up!

Username:

Password:

Login

Remember me

Have you forgotten your password? Enter your details and we will send you an email with your password

No site registration, você deve seleccionar o idioma. Se for o 1º acesso clicar em **Sign Up !**

Onde lá você irá criar :

- Usuário
- Adicionar o e-mail
- Adicionar a data de nascimento

Importante :

A senha para acesso será enviada para o e-mail cadastrado no resgistration no fim do processo.

Senha de 2º Nível – Criando acesso

Introdução

Gerando a senha de 2º nível no site “Registration” para acessar o menu de serviço do inversor

Registration

Language: English

Requests history | **Request password inverter** | Download | User options | Logout

In order to request the password you have to insert the model of the inverter (which can be selected in the pull-down list), the S/N (serial number), the WK/YR (week/year of production of the inverter) and the Update Ver.. This information is available on the display of the inverter: S/N and WK/YR in the menu "INFORMATION – Serial Number"; the Update Ver. in the menu "INFORMATION – Firmware – Update Ver."

The S/N of the inverter must be composed by 6 digits; WK (week/year of production) must be inserted in the WKYR format, without the interposition of any digit. Update Ver. must be composed by 5 digits, as it appears in the display of the inverter.

In case the inverter does not have this heading, or it has the heading "NONE", please let it empty.

Inverter model:	Update Ver.:	S/N Inverter:	Week / year of production:	Note
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				

Inverter model: PVI-2000(-OUTD)-XX

Update Ver.:

S/N Inverter:

Week / year of production:

Ao entrar no site clicar em **Request password Inverter**
Nessa parte você deve selecionar

- **Modelo do Inversor** (ele deve ser igual)
- **Colocar o número de série** (S/N)
- **Colocar o número WW/YY**

Importante :


Essas informações estão todas na etiqueta do inversor. Não é necessário preencher Update de Firmware.

Senha de 2º Nível – Criando acesso

Introdução

Gerando a senha de 2º nível no site “Registration” para acessar o menu de serviço do inversor

Registration



Language: English

Requests history Request password Inverter Download User options Logout

In order to request the password you have to insert the model of the inverter (which can be selected in the pull-down list), the S/N (serial number), the WK/YR (week/year of production of the inverter) and the Update Ver.. This information is available on the display of the inverter: S/N and WK/YR in the menu "INFORMATION – Serial Number"; the Update Ver. in the menu "INFORMATION – Firmware – Update Ver."
The S/N of the inverter must be composed by 6 digits; WK (week/year of production) must be inserted in the WKYR format, without the interposition of any digit. Update Ver. must be composed by 5 digits, as it appears in the display of the inverter.
In case the inverter does not have this heading, or it has the heading "NONE", please let it empty.

Inverter model:	Update Ver.:	S/N Inverter:	Week / year of production:	Note
UNO-2 04-OUTD	12345	123456	0513	
PVI-3 0-OUTD-XX		987654	0412	
TRIO-27 6-TL-OUTD	13052	564789	4812	
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				
PVI-2000(-OUTD)-XX				

Do request

Add other 10 rows

Após preencher os dados e clicar em **Do Request**

Na tela irá aparecer na tela a senha de 2º nível com 6 dígitos.



request_done

Le password richieste:

Inverter model:	S/N Inverter:	Week / year of production:	Password	Expire date
TRIO-50 0/60 0-TL-OUTD	123456	5018	736016	2018-10-22
TRIO-TM-50 0/60 0	346789	5018	999378	2018-10-22

Ricordiamo che saranno valide a tutto il 10-22-18

Click on the window to close or wait 30 seconds

txt_serialesent

Importante :

Essa senha tem validade de 30 dias, após essa data ela expirará e deverá ser feita uma nova senha caso seja necessário.

—

ABB